

Bloom

Tear sheet — Residential non-woven paper



EH022BB Blue



EH022BP Plum



EH022BS Sage



EH022BC Smoke



EH022BH Charcoal



EH022BF Coffee



EH022BM Caramel



Billowing cloud-like shapes bloom and disperse through the atmosphere

Design

Bloom

Pattern number / colour

EH022BB Blue EH022BP Plum EH022BS Sage EH022BC Smoke EH022BH Charcoal EH022BF Coffee

EH022BM Caramel Composition

Non-woven paper, pearl finish

Roll size

Ships as a roll containing 3 panels each measuring 27" wide x 118" high / 68.6cm wide x 3m high

Horizontal repeat

81" / 205 wide

Length

9.8 yards / 9m

Area

66.2ft² / 6.15m²

Fire Rating

Class A, ASTM E84
Euro Class B BS EN 13823: 2002
and BS EN 13238: 2010
BS EN 13501-1: 2007
NZ Group Number 1-S

Environment

Our non-woven paper is sourced from sustainable forest sources and printed using non-toxic inks

Installation

Butt join

Custom colours, finishes and commercial grade qualities are available

1 x Roll (81" / 205cm)

Panel A Panel B Panel C 27"/68.6cm 27"/68.6cm



Installation instructions

Please read these instructions carefully before hanging this wallcovering. It is advisable that a professional decorator is used. If you have any questions please contact us before installing.

BEFORE YOU BEGIN

- Before cutting and hanging this wallcovering, ensure that all rolls have the same batch reference, are in good condition, have no shade variation and that no other faults are present. Please ensure that there are enough rolls to complete the job. Examination before hanging is the buyer's responsibility. No claim can be accepted for hanging incorrect wallcoverings or after wallpapers have been cut and hung showing defects that were apparent at time of hanging or for consequential loss.
- If you have any reservations, please contact us before hanging at mail@emmahayestextiles.com
- This product consists of three panels supplied and printed as one continuous roll. Each panel measures 27" wide x 118" high (68.6cm wide x 300cm high).
- Take extra care when papering around electric light switches and power points. Do not allow moisture to drip onto electrical contacts.

PREPARATION

- Walls should be clean, dry and even.
- Prepare wall by removing all traces of dirt, old wallpaper, or loose paint.
- Do not hang wallcoverings on any wall with a history of damp.
- Fill any cracks and allow to dry before hanging.
- Absorbent surfaces should be appropriately sized using a diluted wallpaper adhesive. Sealed walls, i.e. painted should be rubbed with sandpaper to create a 'key'.

 It is important that the walls are of an even and consistent colour. If they are not then consideration should be given to painting them with an appropriate colourwash. Alternatively, we recommend that walls be 'lined' horizontally using a good quality lining paper. Allow this to fully dry.

HANGING

- This is a 'paste the wall product'. The decorator should paste the wall and not the back of the wallcovering.
- We recommend the use of a light ready mixed adhesive.
 Evenly apply the adhesive directly onto the wall using a brush or a short pile emulsion roller.
- Paste should be evenly applied to the wall to hang one length at a time.
- Apply the wallcovering to the wall and smooth down with a good quality hanging brush or plastic spatula.
- Do not overlap, use butt joins.
- Carefully wipe any excess paste from the face of the paper immediately with a clean damp sponge before it dries.
- After hanging 2 or 3 lengths, inspect the results to ensure that there is no shading or other fault.

No claims for hanging costs will be allowed for goods hung in excess of one roll.

This information has been supplied in good faith, but without guarantee. Site conditions are beyond our control. It is the responsibility of the buyer to ensure that the environment is suitable for the wallcovering.

CARE

Wipe with a soft cloth and clean water. Oils, fats and solvent based stains are not expected to be removable.











INSTALL

paste the wall wet removable

strippable

spongeable

half sun

butt join